

REINER timeStamp 131



Press the [**SELECT**] button to choose the program setting mode. The selected program mode is indicated by the [▲] mark on the display.



Pressing the [**CHANGE**] (+ or -) buttons allows you to cycle through the options in the programming mode you are in. (“+” mean the number pass to increase. “-” mean the number pass to reduce)



Pressing the [**SET**] button allows you to set (enter/lock) the option shown on the display.

PRINT ORDER 1 M.D.H.Min 15 M.D.Y.C Y = Year 2 D.M.H.Min 16 D.M.Y.C M = Month 3 M.D.Y.H.Min 17 Y.M.D.C D = Date 4 D.M.Y.H.Min 18 C.D.H.Min H = Hour 5 Y.M.D.H.Min 19 N.M.D.Y Min = Minute 6 Y.M.D.H.Min.S 20 N.D.M.Y S = Second 7 D.H.Min 21 N.Y.M.D C = Comment 8 DOW.D.H.Min 22 M.D.Y.N N = Number 9 Y.M.D 23 D.M.Y.N DOW = Day of the week 10 M.D 24 Y.M.D.N Print Arrangement 11 DOW.D.M.Y 25 N.D.H.Min 1. Left orientated 12 C.M.D.Y 26 N.M.D.H.Min 2. Center orientated 13 C.D.M.Y 27 N.Y.M.D.H.Min 3. Right orientated 14 C.Y.M.D 28 N.Y.M.D.H.Min.S 29 N 30 Customized Comments			YEAR DIGIT 1 = 2 Digits 2 = 4 Digits Minute 1 = 1/60 2 = 1/100 3 = 1/20 4 = 1/10 LEADING ZERO 1 = Disabled 2 = Enabled		PRINT STYLE 1 = RCVD 7 = PAID 2 = SENT 8 = USED 3 = IN 9 = FAXED 4 = OUT 10 = VOID 5 = CFMD 11 = ORIGN 6 = FILED 12 = APP'D 13 = CMLP'D Customized Comments <input type="checkbox"/> Comment line <input type="checkbox"/> Character Position <input type="checkbox"/> Character Code	
RESET			LANGUAGE 1 = ENGLISH 2 = SPANISH 3 = GERMAN 4 = FRENCH 5 = ITALIAN 6 = PORTUGUESE 7 = NUMERIC		Print Direction 1 = right 2 = left Print Activation 1 = Automatc 2 = Semi-automatic 3 = Manual 4 = Combination	
DISPLAY <input type="checkbox"/> Sec <input type="checkbox"/> Hour <input type="checkbox"/> Min <input type="checkbox"/> Year 1 = 12 hour <input type="checkbox"/> Month 2 = 24 hour <input type="checkbox"/> Date			PRINT ORDER TIME DATE HOUR PRINT ORDER ☀ SU MO TU WE TH FR SA		PRINT PATTERN COMMENT LANGUAGE PRINT METHOD	
<input type="checkbox"/> DAYLIGHT SAVING TIME (START / END) <input type="checkbox"/> YEAR <input type="checkbox"/> MONTH <input type="checkbox"/> DATE			<input type="checkbox"/> NUMBER <input type="checkbox"/> Number Digit <input type="checkbox"/> Repeat Times <input type="checkbox"/> Reset		<input type="checkbox"/> INITIAL NUMBER	
PASSWORD BUZZ EXT SIGNAL OFF ON TIME TABLE PROGRAMM EXT. SIGNAL BUILT-IN BUZZ <input type="checkbox"/> SIGNAL <input type="checkbox"/> BUZZER			<input type="checkbox"/> Program No <input type="checkbox"/> Hour <input type="checkbox"/> Minute		<input type="checkbox"/> Program No <input type="checkbox"/> Day of the week <input type="checkbox"/> Action	